



Fitting Instructions

Before You Start

1. Prepare half a cup of boiling water



2. Remove fittings from bag and twist apart so you have four separate pieces

Hose Connectors

Universal Tap Connector

Accessory Connector



STEP 2

Fitting Universal Tap Connector

Remove the reducer if necessary and screw the Universal Tap Connector tightly onto tap



STEP 1

Fitting Hose Connectors

1. Ensure the hose is cut square



2. Slide yellow nut onto hose



3. Push white split ring onto hose so that it sits flush with the hose edge



4. Submerge hose and split ring in 2cm of hot water for 5-10 seconds to soften end of hose



5. Place the face of the fitting on a hard, flat surface. Push hose firmly over the stem, **ALL** the way down to the base of the fitting



6. Tighten yellow nut



STEP 3

Fitting Accessory Connector to Gun

Screw the Accessory Connector directly into the Spray Gun



STEP 4

Connecting fittings together

Line up white markers on fittings then twist together until they lock





FITTING INSTRUCTIONS INTRO STARTER KIT

Ph: 1300 900 617
Web: www.hoselink.com.au

USEFUL TIPS

Compatible with Other Products

It's easy to use Hoselink with your existing accessories:

1. Unscrew the click-on fitting from your spray gun or sprinkler.
2. Screw in a Hoselink Accessory Connector
OR if you can't unscrew, use a Hoselink Click-on Adapter Set (2491).

Joining Hoses

To join 2 hoses, fit each hose end with a Hose Connector and connect the fittings together.

Release Water Pressure

Turn off tap and release water pressure in gun before disconnecting fittings or you risk dislodging an O-Ring.

Spare O-Rings

Spare O-Rings are supplied in case they become dislodged from the fitting. To replace, press a spare O-Ring into the groove in the face of the connector.

Thin Walled Hoses

If the wall of your hose is very thin and you are experiencing leaking, use secateurs to cut a further 2mm off the White Split Ring. This ensures the Split Ring can grip tightly around the hose.

Any Questions?

Call: 1300 900 617

Email: hoselink@hoselink.com.au

Visit: www.hoselink.com.au

TROUBLESHOOTING

Leaking Fittings

1. Check O-Rings: Check the face of each fitting for a black O-Ring. If an O-Ring is missing from either fitting, replace with a spare O-Ring supplied with this kit. Use only Hoselink supplied O-Rings. If none are available, please contact Hoselink.

2. Remove the Hose Connector from your hose:

- a) Unscrew the yellow nut
- b) Use a small screwdriver to wedge the White Split Ring back up the hose
- c) Submerge the entire fitting in boiling water for 10 seconds
- d) Drain the water away, place the fitting between your feet and firmly pull the hose straight upwards.

3. Re-fit the Hose Connector as per instructions & ensure:

- The hose is cut straight
- The White Split Ring is flush with the end of the hose
- Boiling water is used
- The hose is pushed down as far as it will go

Leaking at the Tap

1. Unscrew the Universal Tap Connector and check the black washer in the top of the connector. If the washer is damaged or missing, please contact Hoselink.

2. Screw the Universal Tap Connector **tightly** back onto the tap, making sure it is not cross threaded.