MODEL: L125

Patterned Solar Wall Light
1 LED | 4 Pack | ORBIT

User Manual

MODEL: L125
Patterned Solar Wall Light
1 LED | 4 Pack | ORBIT

For more information visit

hoselink.com.au

or call

1300 900 617

Cultivating **Connections**

▶ youtube.com/hoselink

HOSELINK®

Kit Contents

4 x Removable solar panel
4 x Decorative frame
2 x Hardware packs include: 2 x Screws and 2 x Masonry plugs

The dim mood lighting creates a gorgeous pattern effect against any surface or backdrop. The light comes complete with a built-in intelligent sensor that automatically illuminates at night and turns off at dawn.

Activate the Light

To activate the light, remove the solar panel from the frame using the small opening on the back of the light, allowing you to lift it out. Click the on/off button, then push the solar panel back into the frame. To test the light, hold your hand over the solar panel and check whether the light comes on.

Product Installation

STEP 1 Find a suitable location

Solar lights need access to direct sunlight for optimum results; preferably 6–8 hours per day.

STEP 2 Install the light

Product Installation – Option A

Using Hoselink Outdoor Acrylic Double-Sided Tape (SKU L100), sold separately

Clean the surface you will adhere to, ensuring it is free of dirt and dust.

Adhere the tape onto the back of the light then press onto the mounting surface firmly.

Product Installation – Option B

Wall or fence mount using supplied hardware pack

B.1 Mark the holes with a marker pen.

B.2 For masonry, use a 6mm masonry drill bit to drill the two holes. Gently hammer the plugs into place and then secure the screws tightly.

B.3 For timber, drill 3mm pilot holes first before drilling the screws into place (plastic plugs are not required).

Specifications

Solar panel	2V / 0.4W Monocrystalline
NI-MH battery	1.2v 600mAh
Operating time	10-12 Hours
Charge time	8 hours
Size	H103mm x W83mm x D52mm
Waterproof rating	IP54
Light temperature (Kelvins)	3000 - 3200K
LED lumens	24-26 Lumens
Effective range	1-1.5 meters/ 120 degrees

NOTE: TO ACTIVATE THE LIGHT AFTER PURCHASE, CHARGE UNDER FULL SUNLIGHT. ENSURE NOTHING IS OBSTRUCTING THE SOLAR PANEL OTHERWISE THE LIGHT WILL NOT CHARGE.

WE RECOMMEND CLEANING THE SOLAR PANEL PERIODICALLY TO MAINTAIN OPTIMAL PERFORMANCE.

WARNING: DO NOT USE THIS LIGHT UNDERWATER OR IN LOW-LYING PUDDLES.