

User Manual

Model: L234 | Wall-mount Solar Floodlight with Sensor 77LED - 4 Pack



The Wall-mount Solar Floodlight comes with a large solar panel and 77 super bright LEDs ideal for use as a security light for added property protection, or for illuminating driveways, paths and patios.



Lighting Modes

1. Medium Light Mode - Light automatically comes on at dusk and off at dawn. Overnight light duration depends on amount of light exposure to the solar panel during the day.
2. Dim Light Sensor Mode - Continuously emits a dim light from dusk to dawn, with a bright light for 15-20 seconds when motion is detected.
3. Bright Sensor Mode - Light remains in standby mode until motion is detected and bright light is emitted for 15-20 seconds.

Product Installation - OPTION 1

Adhere using Hoselink Outdoor Acrylic Double Sided Tape (SKU L100).

Product Installation - OPTION 2

Follow these steps to mount to the wall or fence using the supplied plugs and screws:

Step 1 - Find a suitable location

Solar lights need access to direct sunlight for optimum results, preferably 6-8 hours per day. The motion sensor will detect movement up to 5m away.

Step 2 - Mounting the solar light

Use a 6mm drill piece for masonry installation. Gently hammer the plugs into place and then secure the screws tightly. For timber use a 3mm drill piece without the plugs.

Step 3 - Turn on the light

To activate the light, turn on the switch on the back of the unit. Test by covering the solar panel completely to check that the light comes on. The light is now ready for use.

Note: If the light does not turn on this could be due to the battery not being charged. Leave out in direct sunlight for 6 – 8 hours and try again.

For more information visit
www.hoselink.com.au
or call 1300 900 617