

User Manual

Model: L280 | Adjustable Solar Mounted Spotlight 8LED



The Adjustable Solar Mounted Spotlight combines the advantages of a floodlight and spotlight making the lighting range further and wider. Featuring 360degree adjustable head with motion sensor this light is great for entranceway and security lighting.

HOSELINK[®] 

Lighting Mode

Dim Light with sensor mode – continuously emits a dim light (6LEDs) from dusk until dawn, with a bright light for 15-20seconds when motion is detected.

Product Installation

Follow these steps to mount to the wall or fence using the supplied plugs and screws:

Step 1 - Find a suitable location

Solar lights need access to direct sunlight, preferably 6-8 hours per day. The motion sensor will detect movement up to 5m away.

Step 2 - Mounting the solar light

Use a 6mm drill piece for masonry installation. Gently hammer the

plugs into place and then secure the screws tightly. For timber drill a 3mm pilot hole to guide the screws into place (Plastic plugs are not required).

Step 3 - Turn on the light

To activate the light, turn on the switch on the side of the unit. Turn this on to desired setting. Test by covering the solar panel completely to check that the light comes on. The light is now ready for use.

Note: If the light does not turn on this could be due to the battery not being charged. Leave out in direct sunlight for 6 – 8 hours and try again.

For more information visit
www.hoselink.com.au
or call 1300 900 617