



MODEL: L110
Round Solar Wall Lights | 1LED |
2 Pack | FLAIR

For more information visit

hoselink.com.au

or call


1300 900 617

Cultivating **Connections**

 youtube.com/hoselink

User Manual

MODEL: L110
Round Solar Wall Lights | 1LED |
2 Pack | FLAIR



HOSELINK[®]

Kit Contents

2x Round Solar Wall Light
2x Screws
2x Masonry Plugs

A highly decorative light that will beautify and enhance your outdoor space. We recommend grouping multiple lights with even spacing for a dramatic effect.

Lighting Modes

Once activated, the light automatically turns on at dusk and switches off at dawn.

To activate the light, turn on the switch on the back of the unit. Test by covering the solar panel completely to check that the light comes on. The light is now ready for use.

Product Installation

STEP 1 Find a suitable location

Solar lights need access to direct sunlight for optimum results; preferably 6-8 hours per day.

STEP 2 Install the light

Installation - Option 1

Using adhesive outdoor tape.

Adhere using Hoselink Outdoor Acrylic Double-Sided Tape (SKU L100), sold seperately. Be sure to stick the tape in a cross pattern on the back of the solar light.

Installation - Option 2

Using supplied hardware.

Use a 6mm drill piece for masonry installation. Once your hole is drilled, gently hammer the plugs into place and then secure the screws tightly. For timber, use a 3mm drill piece without the plugs. Hang the light and enjoy.

Be sure to clean the solar panel periodically to maintain optimal performance.

Specifications

Solar panel	2V / 0.25W
LED Lumens	6 lumens
Light Colour	Warm
Lithium Battery	600mAh / 1.2V
Charge Time	8 hours
Working Time	20 hours
Number of Lights	1 LED per light
Solar Panel Size	50w x 25d mm
Water Proof Rating	IP65
Light Size	90w x 90h x 50d mm
Materials	ABS & PC

NOTE: if the light does not turn on, this could be due to the battery not being charged. Leave out in direct sunlight for 6-8 hours and try again.