



MODEL: L112
Solar Up & Down Wall Light | 4 LED |
Warm White |GALLERY

For more information visit

hoselink.com.au

or call

1300 900 617

Cultivating **Connections**

 youtube.com/hoselink



User Manual

MODEL: L112
Solar Up & Down Wall Light | 4 LED |
Warm White |GALLERY



HOSELINK[®]

Kit Contents

2 x Up & Down Wall Lights

2 x Hardware Kit

4 x Screws

4 x Masonry Plugs

The perfect lighting solution to add a touch of elegance and sophistication to your outdoor space. With its sleek design and warm white glow, this light will transform your home's exterior into a captivating gallery.

Lighting Modes

The Up & Down Wall Light has 2 modes:

- 1 Low Light
- 2 High Light

Activate the light

Use the "On/Off" button located on the bottom of the solar light to turn the lights on. To test the light, hold your hand over the solar panel and check if the light comes on.

The same button controls the two different lighting modes and will cycle between, low light, high light, and off.

Product Installation

STEP 1 Find a suitable location

Solar lights need access to direct sunlight for optimum results; preferably 6-8 hours per day.

STEP 2 Install Solar Light

Product Installation – Option A

Using supplied hardware

- A.1** Mark out holes with a marker pen.
- A.2** Use a 6mm drill bit for masonry installation to drill the two holes. Gently hammer the plugs into place and then secure the screws tightly.
- A.3** For timber, drill 3mm pilot holes to guide screws into place (plastic plugs are not required).
- A.4** Be sure to leave some of the screw hanging out as the light hangs like a picture.

Product Installation – Option B

Using adhesive outdoor tape

B.1 Adhere using Hoselink Outdoor Acrylic Double-Sided Tape (SKU L100), sold separately. Stick the tape onto the back of the light then adhere to a clean, dry surface.

Specifications

Solar panel	Monocrystalline Silicon
Lithium battery	3.7V / 1200mAh
Operating time	Low 10 hours, High 6 hours
Charge time	6 hours
Light temperature (Kelvins)	2800 - 3200K
LED lumens	Low 35, High 43
Number of LEDs	4

WARNING: Do not use this light underwater or in low-lying puddles.