



MODEL: L331
Tiki Solar Light | 2 Pack | Flame

For more information visit

hoselink.com.au

or call

1300 900 617

Cultivating **Connections**

 youtube.com/hoselink



User Manual

MODEL: L331
Tiki Solar Light | 2 Pack | Flame

HOSELINK[®]

Kit Contents

- 2 x Tiki solar light
- 2 x Top components (A)
- 2 x Middle components (B)
- 2 x Ground spike (C)



Dreaming of a tropical island holiday? Bring your holiday home and liven up your living space with these realistic flickering flame tiki lights. The light comes complete with a built-in intelligent sensor that automatically illuminates at night and turns off at dawn.

Activate the light

Use the 'ON/OFF' button located on the bottom of the solar light to turn the lights on. To test the light, hold your hand over the solar panel and check if the light comes on. Please make sure this is done before the ground spike is assembled as it covers the 'ON/OFF' button.

Product installation

1 Find a suitable location

Solar lights need access to direct sunlight for optimum results; preferably 6-8 hours per day.

2 Assemble the ground spike

Slot the 3 ground spike components together (A, B, C). Then, line the tabs on the top component (A) up with the slots on the base of the solar light and twist until they lock into place. Finally, push the spike into the ground.

Be sure to clean the solar panel periodically to maintain optimal performance.

Specifications

Solar panel	Polycrystalline
Battery	NI-MH
Operating time	6–8 hours
Charge time	8–10 hours
Light temperature (Kelvins)	1400K
LED lumens	10–15 Lumens
Number of LEDs	54 LEDs

NOTE: if the light does not turn on, this could be due to the battery not being charged. Leave out in direct sunlight for 6–8 hours and try again.