



MODEL: L511
Stainless steel Solar Bollard |
Motion Sensor | LUMINOUS

For more information visit

hoselink.com.au

or call

1300 900 617

Cultivating **Connections**

 youtube.com/hoselink



User Manual

MODEL: L511
Stainless steel Solar Bollard | Motion
Sensor | LUMINOUS

HOSELINK[®]

Kit Contents

- 1 x Stainless Steel Solar Bollard
- 1 x Ground Spike
- 1 x Hardware Kit (2 x screws, 2 x masonry plugs)

An elegant lighting solution that combines modern design with sustainable technology. With its built-in motion sensor and exceptional luminosity, this solar light is the perfect addition to any outdoor space, providing both style and functionality.

Lighting Modes

- 1 Constant Dim Light** - A dim light is displayed continuously from dusk until dawn.
- 2 Sensor with Dim Light** - A dim light is displayed continuously from dusk until dawn. When motion is detected, the light brightens for 25 seconds before returning to a dim light.
- 3 Sensor with Bright Light** - The light will remain off until motion is detected then the brightest light setting will be activated.

Activate the light

Press and hold the white button on the bollard for 3 seconds to turn the light on or off. Once on, press the white button to cycle through each lighting mode until you reach your preferred option. The solar panel has a built-in intelligent light sensor, which detects darkness, automatically illuminating the light at dusk and turning it off at dawn.

Product Installation

STEP 1 Find a suitable location

Solar lights need access to direct sunlight for optimum results; preferably 6-8 hours per day.

STEP 2 Install Solar Light

Product Installation – Option A

Ground Spike

A.1 Push the spike into the base of the solar light until secured then simply push into soft ground in your desired location.

Product Installation – Option B

Using supplied hardware

B.1 Use the light to mark holes with a marker pen.

B.2 For masonry installation use a 8mm drill bit to drill the two holes. Gently hammer the plugs into place and then secure the screws tightly.

B.3 For timber, drill 3mm pilot holes to guide screws into place (plastic plugs are not required).

Specifications

Solar panel	Monocrystalline Silicon
Lithium battery	3.7V / 1200mAh
Operating time	Model 1: 22LM 18H, Model 2: 96LM 5H, Model 3: 188LM 2H
Charge time	8 hours
Light temperature (Kelvins)	3000K
LED lumens	Model 1: 20, Model 2: 90, Model 3: 180
Number of LEDs	12

WARNING: Do not use this light underwater or in low-lying puddles.